



Neptune® 360™  
File Mapper Layout  
Version 1.4

**Accu-Flo**  
1-800-921-2228  
[www.accuflo.com](http://www.accuflo.com)





Neptune® 360™  
File Mapper Layout  
Version 1.4

## Copyright

This manual is an unpublished work and contains the trade secrets and confidential information of Neptune Technology Group Inc., which are not to be divulged to third parties and may not be reproduced or transmitted in whole or part, in any form or by any means, electronic or mechanical for any purpose, without the express written permission of Neptune Technology Group Inc. All rights to designs or inventions disclosed herein, including the right to manufacture, are reserved to Neptune Technology Group Inc.

Neptune engages in ongoing research and development to improve and enhance its products. Therefore, Neptune reserves the right to change product or system specifications without notice.

## Trademarks Used in This Manual

Neptune is a registered trademark of Neptune Technology Group Inc.

Neptune 360 is a trademark of Neptune Technology Group Inc.

Other brands or product names are the trademarks or registered trademarks of their respective holders.



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the software.

Neptune<sup>®</sup> 360<sup>™</sup> File Mapper Layout v1.4  
Literature No. FL Neptune 360 File Mapper 03.20

Neptune Technology Group Inc.  
1600 Alabama Highway 229  
Tallahassee, AL 36078  
Tel: (800) 633-8754  
Fax: (334) 263-7293

Copyright © 2020  
Neptune Technology Group Inc.  
All Rights Reserved

*Chapter 1: General Information* ..... 1

    Glossary ..... 1

    References ..... 1

    Character Types ..... 2

*Chapter 2: Import File* ..... 3

    File Types / Extensions ..... 3

    Header Row ..... 3

    Import Record ..... 4

    Record and Field Formatting ..... 4

    Data Formatting Examples ..... 4

    Field Use Requirements ..... 5

        REQUIRED Fields ..... 5

            Account Holder City ..... 5

            Account Holder Delivery Address ..... 6

            Account Holder Name ..... 6

            Account Holder State ..... 6

            Account Holder Zip ..... 7

            Account Number ..... 7

            Account Status ..... 7

            Company ..... 8

            Customer Name ..... 8

            Cycle ..... 9

            Decimals ..... 9

            Meter Manufacturer ..... 9

            Meter Number ..... 10

            Meter Size ..... 10

Number of Dials .....	10
Office .....	11
Premises City .....	11
Premises Delivery Address .....	11
Premises Key .....	12
Premises State .....	12
Premises Zip .....	12
Read Sequence .....	13
Register ID .....	13
Register Manufacturer .....	13
Register Multiplier .....	14
Register UOM .....	14
Route .....	14
OPTIONAL Fields .....	15
Account Holder Email .....	15
Account Holder Phone .....	15
High Limit .....	15
IsSensor .....	16
Low Limit .....	16
Meter Latitude .....	16
Meter Longitude .....	17
Meter Type .....	17
MIU ID .....	17
Premises Email .....	18
Premises Phone .....	18
Previous Read .....	18
Read Type .....	18

Special Instruction 1 .....	19
Special Instruction 2 .....	19
Utility Custom 1 .....	19
Utility Custom 2 .....	19
Utility Custom 3 .....	19
Utility Custom 4 .....	20
Utility Custom 5 .....	20
Utility Custom 6 .....	20
Utility Custom 7 .....	20
Utility Custom 8 .....	20
Utility Custom 9 .....	20
Utility Custom 10 .....	20
<b>Chapter 3: Export File .....</b>	<b>21</b>
Export Header Row .....	21
Export Record .....	22
ROUTE MANAGEMENT .....	23
Company .....	23
Office .....	23
Cycle .....	23
Route .....	23
ACCOUNT and PREMISES INFORMATION .....	24
Account Number .....	24
Premises Key .....	24
METER READING INFORMATION .....	24
METER READING_A .....	25
Meter Number_A .....	25
MIU ID_A .....	25
Register ID_A .....	25

Reading_A .....	25
Raw Reading_A .....	26
Read DateTime_A .....	26
35 Day No Flow flag_A .....	26
Reverse Flow flag_A .....	27
35 Day Leak flag_A .....	27
Current Leak flag_A .....	28
Reader ID_A .....	28
Order Status_A .....	29
Skip Code_A .....	29
Comment Code 1_A .....	29
Comment Code 2_A .....	29
Note_A .....	30
Re-entry Count_A .....	30
METER READING_B .....	30
Meter Number_B .....	30
MIU ID_B .....	30
Register ID_B .....	30
Reading_B .....	30
Raw Reading_B .....	31
Read DateTime_B .....	31
35 Day No Flow flag_B .....	31
Reverse Flow flag_B .....	31
35 Day Leak flag_B .....	31
Current Leak flag_B .....	31
Reader ID_B .....	31
Order Status_B .....	31



---

Skip Code_B .....	31
Comment Code 1_B .....	31
Comment Code 2_B .....	31
Note_B .....	31
Re-entry Count_B .....	31
METER READING_C .....	32
Meter Number_C .....	32
MIU ID_C .....	32
Register ID_C .....	32
Reading_C .....	32
Raw Reading_C .....	32
Read DateTime_C .....	32
35 Day No Flow flag_C .....	32
Reverse Flow flag_C .....	32
35 Day Leak flag_C .....	32
Current Leak flag_C .....	32
Reader ID_C .....	32
Order Status_C .....	33
Skip Code_C .....	33
Comment Code 1_C .....	33
Comment Code 2_C .....	33
Note_C .....	33
Re-entry Count_C .....	33
METER READING_D .....	33
Meter Number_D .....	33
MIU ID_D .....	33
Register ID_D .....	33

Reading_D .....	33
Raw Reading_D .....	33
Read DateTime_D .....	34
35 Day No Flow flag_D .....	34
Reverse Flow flag_D .....	34
35 Day Leak flag_D .....	34
Current Leak flag_D .....	34
Reader ID_D .....	34
Order Status_D .....	34
Skip Code_D .....	34
Comment Code 1_D .....	34
Comment Code 2_D .....	34
Note_D .....	34
Re-entry Count_D .....	34
METER READING_E .....	35
Meter Number_E .....	35
MIU ID_E .....	35
Register ID_E .....	35
Reading_E .....	35
Raw Reading_E .....	35
Read DateTime_E .....	35
35 Day No Flow flag_E .....	35
Reverse Flow flag_E .....	35
35 Day Leak flag_E .....	35
Current Leak flag_E .....	35
Reader ID_E .....	35
Order Status_E .....	36

Skip Code\_E .....36

Comment Code 1\_E ..... 36

Comment Code 2\_E ..... 36

Note\_E ..... 36

Re-entry Count\_E .....36

UTILITY PASS THROUGH ..... 36

Utility Custom 1 .....36

Utility Custom 2 .....36

Utility Custom 3 .....36

Utility Custom 4 .....37

Utility Custom 5 .....37

Utility Custom 6 .....37

Utility Custom 7 .....37

Utility Custom 8 .....37

Utility Custom 9 .....37

Utility Custom 10 ..... 37

Export Record Terminator .....37

This page intentionally left blank.

Table 1: Glossary Terms ..... 1

This page intentionally left

Neptune® 360™ supports the import and utilization of “flat” files for the purposes of transferring data between a utility’s Customer Information System (CIS) and Neptune 360. These flat files are not required to have a hierarchical record structure, are plain text-based, and use delimited variable-length fields rather than fixed-length fields and records. Support for flat files allows implementers to begin inter-operating with Neptune 360 more rapidly. In many cases, a CIS may be able to support a flat transfer file with little to no intervention from the CIS vendor.

### Glossary

---

Table 1 contains terms referenced throughout this document.

**Table 1: Glossary Terms**

Term	Definition
Customer Information System (CIS)	The software used by a utility to conduct billing and revenue collection processes.
Delimited	The boundaries between field values in each record / row are indicated by a specific text character.
Import File	A file created by and transferred out of the CIS to be imported into Neptune 360.
Export File	A file created by Neptune 360 to be imported into CIS.
Meter Configuration	A combination of a meter body and register which can also include an integrated or stand-alone radio (MIU).
Premises	The physical location at which a utility service is provided and measured.

### References

---

The following is a list of references used in this guide.

- RFC 2119 — "Key words for use in RFCs to Indicate Requirement Levels," <https://tools.ietf.org/html/rfc2119>.
- RFC 5234 — "Augmented BNF for Syntax Specifications: ABNF," <https://tools.ietf.org/html/rfc5234>.

## Character Types

---

For both the import and export file, field definitions include a character type specifying the expected data within that field. Character types are shown in a different font throughout this document (***DIGIT*** for example,) and when used they are to be interpreted as described below and as adapted from RFC 5234. Character types do not directly reflect nor prescribe the database types used to store field values.

- ***ALPHA*** – ASCII letters A-Z or a-z (%x41-5A or %x61-7A).
- ***CRLF*** – Standard carriage return linefeed characters (%x0D and %x0A).
- ***DIGIT*** – Numbers 0 - 9 (%30x-39).
- ***DQUOTE*** – Double quote " (%x22).
- ***SP*** – Space character (%x20).
- ***ALPHANUM*** – Visible characters (%x21-7E) and spaces (%x20) are allowed.
- ***VTEXT*** – Visible characters (%x21-7E), accented ASCII letters (%80-A5), and spaces (***SP***) are allowed.
- ***DECIMAL*** – Only numbers (***DIGIT***) and the punctuation characters en dash (-) or period (.) are allowed (%2D-2E).
- ***BOOL*** – Only the uppercase letters Y or N are allowed (%x59 or %x4E).
- ***EMAIL*** – Visible characters (%x21-7E) and punctuation (***PUNCT***) are allowed.
- ***PUNCT*** – Only these characters are allowed: at sign (@), period (.), exclamation (!), number sign (#), dollar sign (\$), percent (%), ampersand (&), single quote ('), asterisk (\*), plus sign (+), en dash (-), forward slash (/), equal sign (=), question mark (?), caret (^), underline (\_), accent mark (`), braces ({ }), and tilde (~).
- ***SIZE*** – Only numbers (***DECIMAL***), the letter x, spaces (***SP***), and the special characters forward slash (/), en dash (-), or ***DQUOTE*** are allowed.
- ***ERRREAD*** – Only numbers (***DIGIT***), special characters colon (:) or question mark (?), or uppercase letters M or U are allowed.
- ***DELIM*** – Vertical bar or pipe character (|) (%x7C).



The import file contains records and field data from a utility's Customer Information System (CIS) and is imported into Neptune® 360™. The imported data is used in billing for service usage, as well as enabling features within Neptune 360 that support meter reading and utility customer service activities.

When a flat file is initially imported into Neptune 360, Neptune personnel perform a manual process to map the fields / columns of data in the utility's imported file to the Neptune 360 internally-supported fields. Then the utility can generate an import-capable file without having to specifically export to a structured file format. After successful completion of the mapping process, the resulting configuration is used for all subsequent imports from the CIS into Neptune 360.

### File Types / Extensions

---

The import file is a plain text-based file. Each file consists of a Header Row followed by one or more records. Each record occupies a row or line in the file. There cannot be a hierarchy of records. Each record consists of multiple variable-length fields and fields that are demarcated by the inclusion of a text delimiter character. The same delimiter character is used throughout the import file.

An import file does not require a specific, pre-defined file extension; however, Neptune 360 requires a flat, delimited text file. File extensions such as .txt, .csv, or .imp can be used. Do not use an extension commonly associated with either a non-text data type such as .jpg, .exe or a formatted text-based file extension such as .rtf or .pdf. Use of such extensions can cause the file to fail validation.

There are no specific naming requirements or conventions for an import file. However, make the file name descriptive, readily identifiable for import into Neptune 360, and differentiate one file from other generated files.

### Header Row

---

A utility's import file contains a Header Row. The Header Row contains all the field names (i.e., column names) included in the file's import records. There can be only one Header Row in a file, and it is the first row / record in the file. The Header Row contains the plain text names of the fields present in the import records and each separated by a delimiter character. The Header Row cannot contain duplicate field names. Each field name needs to be between 1 and 26 *VTEXT* characters.

## Import Record

---

The Import Record is used to transfer account-related data from the CIS into Neptune 360. An import file can have any quantity of Import Records; however, there is at least one Import Record per file. Each data field within an Import Record is separated by a delimiter character and each Import Record in the file ends with *CRLF*. Each Import Record contains the same number of fields as indicated in the header row.

## Record and Field Formatting

---

This list provides information on formatting a field.

- Each row / line for a specific record type contains the same quantity of fields.
- Every field in a record except the final field ends with a delimiter character, even if the field is not populated with data. The final field in a record cannot end with a delimiter character.
- When a field is populated, data cannot include preceding or trailing space characters—white space may be trimmed by the system.
- Field data containing letters are not case-sensitive; "ABCD", "abcd", "aBcD" are considered the same values.
- Field data containing commas, spaces, double quotes, or other escapable characters can be enclosed within two *DQUOTE* characters (example: "Smith, John".) A double quote inside the field can be preceded (i.e., escaped) with another *DQUOTE* (examples: 5/8"" or "5/8""").
- Every record is terminated with a *CRLF*. The *CRLF* for the final record in the file also serves as the end of file indicator. Note that *CRLF* characters are non-visible and non-printing and are represented as letters or symbols throughout this document for illustrative purposes only.

## Data Formatting Examples

---

The following example has three records and each record has four fields. Each field is separated from the next by a delimiter character—in these examples, the vertical bar or pipe | character—and there is no delimiter character between the last field and record-terminating *CRLF*.

**record1field1 | field2 | field3 | field4CRLF**

**record2field1 | field2 | field3 | field4CRLF**

**record3field1 | field2 | field3 | field4CRLF**

In this example, **field2** data contains a comma, a space, and is enclosed within two *DQUOTE* characters.

```
record4field1|"field, 2"|field3|field4CRLF
```

In this example, the second and third fields are optional and have not been specified. They must have their own delimiter character to demarcate the fields and to ensure the field count is correct for that record.

```
record5field1||field4CRLF
```

In this example, the record contains spaces at the end of **field1** and at the beginning of **field3**. Neither condition is prohibited, but both are discouraged. These extraneous spaces can cause validation and data integrity issues within Neptune 360.

```
record6field1 |field2| field3|field4CRLF
```

## Field Use Requirements

---

Each field in the import file is either required or optional.

- A REQUIRED field is populated with data that complies with their corresponding field specifications.
- An OPTIONAL field can either be populated with data or left empty. However, when an optional field is populated with data, the data must comply with the corresponding field specifications.

## REQUIRED Fields

---

The fields in this section are required by Neptune 360 and have an equivalent field and data in the import file. For each import record field, the field name is given along with a brief description of the field. Requirements for the field's use— including any recognized values—are specified along with the character type, minimum and maximum allowed character counts. Example data is provided for reference; each example includes a reference delimiter character. These fields are listed in alphabetical order.

### *Account Holder City*

Account Holder City indicates the city associated with the account holder address. Account Holder City contains at least 1 and up to 26 *VTEXT* characters.

Examples:

- **Duluth|**
- **La Côte-de-Gaspé|**
- **Española|**

Account Holder City can be the same as Premises City.

### *Account Holder Delivery Address*

Account Holder Delivery Address Indicates the address number and street name associated with the account holder. Account Holder Delivery Address contains at least 1 to 64 *VTEXT* characters.

Examples:

- **3100 Breckinridge Blvd Bldg 2100|**
- **832 Avenue Sévigny|**
- **"1234-A NW Main St S Apt 1201"|**

Account Holder Delivery Address cannot contain the city, state / province, or zip / postal code. Account Holder Delivery Address conforms with the USPS or Canada Post guidelines for Delivery Address Line or Civic Address line, respectively, which can include other address information such as pre-direction, unit, or post direction. Account Holder Delivery Address can be the same as Premises Delivery Address.

### *Account Holder Name*

Account Holder Name indicates the full name or names of the account holder(s). Account Holder Name contains at least 1 and up to 26 *VTEXT* characters.

Examples:

- **Johnny Appleseed|**
- **Hélène François|**
- **"Appleseed, Johnny & Jane"|**
- **Smith, Donna / Jones, Dave|**

Account Holder Name can contain embedded commas, forward slashes, and ampersand characters, especially if representing multiple persons.

### *Account Holder State*

Account Holder State indicates the state or province associated with the account holder delivery address. Account Holder State contains two *ALPHA* characters.

Examples:

- **GA|**
- **ON|**

Account Holder State is expressed as a standardized two-letter abbreviation and is capitalized. Account Holder State can be the same as Premises State.

### Account Holder Zip

Account Holder Zip indicates the zip or postal code associated with the account holder delivery address. Account Holder Zip contains at least 5 and up to 10 characters and is formatted as indicated below.

Examples:

- **30096|**
- **30096 - 4985|**
- **L5N 5M9|**

U.S. zip codes contain at least five *DIGIT* characters and can be followed by a dash and an additional four *DIGIT* characters. U.S. zip codes cannot include spaces. Canadian postal codes have seven total characters and can be in *ALPHA DIGIT ALPHA SP DIGIT ALPHA DIGIT* format. The *ALPHA* characters are capitalized. Account Holder Zip can be the same as Premises Zip.

### Account Number

Account Number identifies the account number associated with the premises. Account Number contains at least 1 and up to 20 *ALPHANUM* characters.

Examples:

- **DLTH0987654321|**
- **abcde12345fghjk67890|**
- **123-0000293847**

Each Account Number is unique within the CIS.

### Account Status

Account Status indicates the current billing status of the customer account. Account Status contains at least one to four *ALPHA* characters. Neptune 360 recognizes four Account Status types:

- **Active** – customer account is active in the CIS.
- **Active Warn on Zero Use** – customer account is active in the CIS; indicate if there is no service usage.
- **Inactive** – customer account is inactive in the CIS.
- **Inactive Warn on Use** – customer account is inactive in the CIS; indicate if there is service usage.

Examples:

- **ACTI** |
- **Inac** |
- **A** |

Minimally, an Account Status value is mapped to Active. Any non-mapped value indicated in Account Status is treated by Neptune 360 as Inactive.

### *Company*

Company identifies the entity administering the locations, offices, and personnel responsible for meter reading and billing. Company contains at least one and up to four *ALPHANUM* characters.

Examples:

- **NEPT** |
- **nep** |
- **00A1** |

Company is most often the name or an abbreviated name of the utility. In Neptune 360, a Route ID is the combination of the Company, Office, Cycle, and Route fields, joined by dash characters.

### *Customer Name*

Customer Name indicates the full name or names of the customers at the address where the meter / service is located. Customer Name contains at least 1 and up to 26 *VTEXT* characters.

Examples:

- **Johnny Appleseed** |
- **Hélène François** |
- **"Appleseed, Johnny & Jane"** |
- **Smith, Donna / Jones, Dave** |

Customer Name can be the same as Account Holder Name, and can contain embedded commas, spaces, forward slashes, and ampersand characters, especially if representing multiple persons.

## Cycle

Cycle identifies a grouping of routes. Cycle contains at least one and up to four *ALPHANUM* characters.

Examples:

- **Mwk1** |
- **0 02** |
- **A** |

Cycle is often a designator for the period in which the accounts within a route are to be billed. In Neptune 360, a Route ID is the combination of the Company, Office, Cycle, and Route fields, joined by dash characters.

## Decimals

Decimals indicate the number of digits placed to the right of the decimal point on a meter reading. Decimals are specified as a one *DIGIT* character with values between zero and eight, inclusive. Decimals can contain two *DIGIT* characters with values between 00 and 08, inclusive.

Examples:

- **0** |
- **01** |

## Meter Manufacturer

Meter Manufacturer names the manufacturer of the meter installed at the premise. Meter Manufacturer contains at least 1 and up to 25 *ALPHANUM* characters. Neptune 360 recognizes the following values: **Neptune**, **Sensus**, **MasterMeter**, **Other**, **Itron**, **Hersey / Mueller**, **Badger**, **Elster / Amco**, **Metron-Farnier**.

Examples:

- **Neptune** |
- **Other** |

Each Neptune 360 Meter Manufacturer value has a mapped import value. Any non-mapped value indicated in Meter Manufacturer are considered as Other by Neptune 360.

### *Meter Number*

Meter Number identifies the physical meter body installed at a premises. Meter Number contains at least 1 and up to 20 *ALPHANUM* characters.

Examples:

- **W1AH8201 |**
- **09876543211234567890 |**

Meter Number is the meter body serial number or other identifier designated by the meter manufacturer and is unique within the CIS. Meter Number can have one or more leading zeros.

### *Meter Size*

Meter Size denotes the size of the meter installed at the premises. Meter size contains at least 1 and up to 20 *SIZE* characters. Neptune 360 recognizes the following core meter size values: *5/8, 3/4, 1, 1 1/2, 2, 3, 4, 6, 8, 10, 12, 16, 20*.

Examples:

- **5/8 |**
- **6x8" |**
- **"1 1/2"" |** (see "Record and Field Formatting" on page 4 for notes on double quotes)

Each Neptune 360 Meter Size value is a mapped import value. Any non-mapped value indicated in Meter Size is considered as 5/8 by Neptune 360. Single fractional characters such as  $\frac{1}{2}$ ,  $\frac{3}{4}$ , and  $\frac{5}{8}$  cannot be used. Alternate lay lengths, decimal equivalents (e.g., .75 for  $\frac{3}{4}$ ), and numeric-only fractional representations (e.g., 58 for  $\frac{5}{8}$ ) can be mapped to a Meter Size.

### *Number of Dials*

Number of Dials indicates the number of digits expected for a meter reading. Number of Dials is specified; it contains one *DIGIT* character with values between one and eight, inclusive. Number of Dials can contain two *DIGIT* characters with values between 01 and 08, inclusive.

Examples:

- **8 |**
- **06 |**



Number of Dials can be used to audit the entered reading and / or to control the reading field size displayed on the handheld device. Number of Dials cannot have a value of 0 or 00 and the value indicated cannot include the decimal nor the digits after the decimal. A register's combined values for Number of Dials and Decimals cannot exceed nine.

### Office

Office identifies an individual location or working group of personnel within the Company. Office contains at least one and up to four *ALPHANUM* characters.

Examples:

- **Off1|**
- **1234|**
- **Of 1|**

In Neptune 360, a Route ID is the combination of the Company, Office, Cycle, and Route fields, joined by dash characters.

### Premises City

Premises City indicates the city where the meter / service is located. Premises City contains at least 1 and up to 26 *VTEXT* characters.

Examples:

- **Duluth|**
- **La Côte-de-Gaspé|**
- **Española|**

Premises City can be the same as Account Holder City

### Premises Delivery Address

Premises Delivery Address indicates the address number and street name where the meter / service is located. Premises Delivery Address contains at least 1 and up to 64 *VTEXT* characters.

Examples:

- **3100 Breckinridge Blvd Bldg 2100|**
- **832 Avenue Sevigny|**
- **"1234-A NW Main St S Apt 1201"|**

Premises Delivery Address cannot contain city, state / province, or zip / postal code. Premises Delivery Address conforms with USPS or Canada Post guidelines for Delivery Address Line or Civic Address line, respectively, which can include other address information such as pre-direction, unit, or post-direction. Premises Delivery Address can be the same as Account Holder Delivery Address.

### *Premises Key*

Premises key provides a unique identifier for a physical premises or service location. Premises Key contains at least 1 and up to 20 **ALPHANUM** characters.

Examples:

- **001-1234567890 |**
- **A270C75BB6398AE02D14 |**
- **"102 /9876543" |**

If an alternate unique key cannot be generated by the CIS, each Premises Key can be the same as Account Number. Premises Key is unique within the CIS and remains the same for any records corresponding with the same premises or location.

### *Premises State*

Premises State indicates the state or province where the meter / service is located. Premises State is two **ALPHA** characters.

Examples:

- **GA |**
- **ON |**

Premises State is expressed as a standardized two-letter abbreviation and is capitalized. Premises State can be the same as Account Holder State.

### *Premises Zip*

Premises Zip indicates the zip or postal code where the meter / service is located. Premises Zip contains at least 1 and up to 10 characters and is formatted as indicated below.

Examples:

- **30096 |**
- **30096-4985 |**
- **L5N 5M9 |**

U.S. zip codes contains at least 5 *DIGIT* characters and can be followed by a dash and an additional four *DIGIT* characters. U.S. zip codes cannot include spaces. Canadian postal codes contains seven characters and i *ALPHA DIGIT ALPHA SP DIGIT ALPHA DIGIT* format. The *ALPHA* characters are capitalized. Premises Zip can be the same as Account Holder Zip.

### *Read Sequence*

Read Sequence is used to convey the order in which meters are expected to be read. Read Sequence contains at least one and up to six *DIGIT* characters.

Examples:

- **13** |
- **000971** |

Each Read Sequence value within a specific route is unique. Read Sequence can have leading zeros and cannot contain spaces.

### *Register ID*

Register ID contains the serial number for the register associated with a meter at a premises. Register ID contains at least 1 and up to 10 *DIGIT* characters.

Examples:

- **1234867530** |
- **2011417** |

The identifier represented in Register ID is unique within a given utility and cannot be repeated within a transfer file.

### *Register Manufacturer*

Register Manufacturer identifies the manufacturer of the register used to collect reading data. Register Manufacturer contains at least 1 and up to 25 *ALPHANUM* characters.

Examples:

- **Neptune** |
- **Other** |

### Register Multiplier

Register Multiplier indicates the value used for multiplication of raw reads when calculating consumption. Register Multiplier contains at least one and up to six *DECIMAL* characters and is a power of 10 between .00001 and 100000.

Examples:

- **0.0001** |
- **1** |
- **100** |

Register Multiplier cannot contain a zero or a dash. The zero before the decimal can be omitted. If the actual value is not known, Multiplier is set to one.

### Register UOM

Register UOM identifies the unit of measure designated by the meter's register. Register UOM contains at least one and up to eight *ALPHANUM* characters and is one of the following values:

**Cubic Feet** = FT3, CF, CF3, CCF, F^3, Cu Ft or Cu. Ft.

**Cubic Meters** = M3, CM, CM3, CCM, M^3, kl, Cu M or Cu. M.

**Gallons** = Gallons, G, Gal. or GAL

**Imperial Gallons** = IPG, Imp gal, Imp. gal. or galUK

**Liters** = LTR, l, liters or DM3

Examples:

- **CCF** |
- **"M^3"** |

### Route

Route identifies the route associated with the cycle to which a premises or account belongs. A Route contains at least 1 and up to 10 *ALPHANUM* characters.

Examples:

- **DuluthGA01** |
- **DULUTH1** |
- **22** |

In Neptune 360, a Route ID is the combination of the Company, Office, Cycle, and Route fields, joined by dash characters.

---

## OPTIONAL Fields

---

The fields in this section are optional for import into Neptune 360. The source import file can contain equivalent fields and data. These fields are listed below in alphabetical order.

### *Account Holder Email*

Account Holder Email indicates an email address associated with the account holder. Account Holder Email can be specified and contain up to 50 **EMAIL** characters.

Examples:

- **marketing@neptunetg.com|**
- **"sales@neptunetg.com" |**

Account Holder Email can be the same as Premises Email.

### *Account Holder Phone*

Account Holder Phone indicates the phone number associated with the account holder. Account Holder Phone can be specified and contain up to 10 **DIGIT** characters.

Examples:

- **5552034032 |**
- **8006338754 |**

Account Holder Phone data is numeric and excludes dashes, spaces, plus signs or parentheses. Account Holder Phone can be the same as Premises Phone.

### *High Limit*

High Limit defines the highest reading expected to be captured for the given register. High Limit can be specified; if present, it contains at least 1 and up to 10 **DIGIT** characters.

Examples:

- **2598 |** (Number of Dials = 4)
- **002598 |** (Number of Dials = 6)

The number of characters used for High Limit matches the value specified for the corresponding Number of Dials. High Limit can contain leading zeros. If a high reading limit is not prescribed by the CIS, High Limit is left empty.

### *IsSensor*

IsSensor denotes whether the device associated with the MIU ID is a sensor device such as a pressure or leak monitor rather than a meter or register. If MIU ID is specified, IsSensor is specified; if present, it is a one **BOOL** character and has a value of either Y or N.

Examples:

- **Y|**
- **N|**

If MIU ID is not specified, IsSensor is empty.

### *Low Limit*

Low Limit defines the lowest reading expected to be captured for the given register. Register Low Limit can be specified; if present, it contains at least 1 and up to 10 **DIGIT** characters.

Examples:

- **2402|** (Number of Dials = 4)
- **002402|** (Number of Dials = 6)

The number of characters used for Low Limit should match the value specified for the corresponding Number of Dials. Low Limit can contain leading zeros. The value for Low Limit is often the same as Previous Read. If a low reading limit is not prescribed by the CIS, Low Limit should be empty.

### *Meter Latitude*

Meter Latitude designates the signed decimal degrees latitude (y-coordinate) corresponding with the meter location. Meter Latitude can be specified; if present, Meter Latitude contains at least 1 and up to 12 **DECIMAL** characters.

Examples:

- **32|**
- **33.963832129|**



All North American latitudes are positive and must not be preceded by a dash. The latitude of the premises can be used to represent Meter Latitude. Meter Latitude should conform to Web Mercator.

### Meter Longitude

Meter Longitude designates the signed decimal degrees longitude (x-coordinate) corresponding with the meter location. Meter Longitude can be specified; if present, Meter Longitude contains at least 1 and up to 12 *DECIMAL* characters.

Examples:

- **-84 |**
- **-84.14464 |**



All North American longitudes are negative and are preceded by a dash. The longitude of the premises can be used to represent Meter Longitude. Meter Longitude should conform to Web Mercator.

### Meter Type

Meter Type is used in conjunction with Read Type to designate a grouping of meters that are expected to be read using the same method. Meter Type contains at least one and up to four *ALPHANUM* characters.

Meter Type examples:

- **0001 |**
- **R900 |**
- **MAN |**

### MIU ID

Contains the serial number / FCC ID for the radio collection device associated with a meter at a premises. MIU ID can be specified; if present, it has at least 1 and up to 13 *DIGIT* characters.

MIU ID examples:

- **1112223333 |**
- **2223334444555 |**

The identifier represented in MIU ID is unique within a given Utility and cannot be repeated within a transfer file. If the radio collection device identifier is unknown, MIU ID should be empty.

### *Premises Email*

Premises Email indicates an email address associated with the customer at the address where the meter / service is located. Premises Email can be specified and up to 50 *EMAIL* characters.

Premises email address: **marketing@neptunetg.com** |

Example: **"sales@neptunetg.com"** |

Premises Email can be the same as Account Holder Email.

### *Premises Phone*

Premises Phone indicates the phone number associated with the customer at the address where the meter / service is located. Premises Phone can be specified and contain up to 10 *DIGIT* characters.

Premises Phone: **3342836555** |

Example: **9058584211** |

Premises Phone data is numeric and excludes dashes, spaces, plus signs or parentheses. Premises Phone can be the same as Account Holder Phone.

### *Previous Read*

Previous Read displays the reading recorded by the CIS for the previous billing period. Previous Read can be specified; if present, it contains at least 1 and up to 10 *DIGIT* characters for a normal, numeric reading.

Previous Read examples:

- **17294** |
- **0000654321** |

Previous Read can contain leading zeros and excludes non-numeric data. If the previous reading recorded by the CIS contained errors / non-numeric data, Previous Read should be empty.

### *Read Type*

Read Type describes the type of read or measurement expected for an individual register. Used in conjunction with Meter Type. Read Type is at least one and up to four *ALPHANUM* characters.



Read Type\_A examples:

- **WAT|**
- **HIGH|**
- **LOW|**

### *Special Instruction 1*

Special Instruction 1 contains account or premises-related information or instructions for use by a meter reader on a handheld device. Special Instruction 1 can be specified and contain up to 300 *VTEXT* characters.

Special Instruction 1: **contact homeowner before accessing property|**

Example: **"gate code = 0625; park to side of garage"|**

### *Special Instruction 2*

Special Instruction 2 contains additional account or premises-related information or instructions for use by a meter reader on a handheld device. Special Instruction 2 can be specified and contain up to 300 *VTEXT* characters.

Special Instruction 2 examples are the same as Special Instruction 1.

### *Utility Custom 1*

Utility Custom 1 allows any utility-defined information to be provided. Utility Custom 1 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 1 examples:

- **Check w/bldg mgr. before accessing meter|**
- **001 /17590378164|**

### *Utility Custom 2*

Utility Custom 2 allows any utility-defined information to be provided. Utility Custom 2 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 2 examples are the same as Utility Custom 1.

### *Utility Custom 3*

Utility Custom 3 allows any utility-defined information to be provided. Utility Custom 3 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 3 examples are the same as Utility Custom 1.

### *Utility Custom 4*

Utility Custom 4 allows any utility-defined information to be provided. Utility Custom 4 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 4 examples are the same as Utility Custom 1.

### *Utility Custom 5*

Utility Custom 5 allows any utility-defined information to be provided. Utility Custom 5 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 5 examples are the same as Utility Custom 1.

### *Utility Custom 6*

Utility Custom 6 allows any utility-defined information to be provided. Utility Custom 6 can be specified and n contain up to 40 *VTEXT* characters.

Utility Custom 6 examples are the same as Utility Custom 1.

### *Utility Custom 7*

Utility Custom 7 allows any utility-defined information to be provided. Utility Custom 7 can be specified and can contain up to 40 *VTEXT* characters.

Utility Custom 7 examples are the same as Utility Custom 1.

### *Utility Custom 8*

Utility Custom 8 allows any utility-defined information to be provided. Utility Custom 8 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 8 examples are the same as Utility Custom 1.

### *Utility Custom 9*

Utility Custom 9 allows any utility-defined information to be provided. Utility Custom 9 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 9 examples are the same as Utility Custom 1.

### *Utility Custom 10*

Utility Custom 10 allows any utility-defined information to be provided. Utility Custom 10 can be specified and contain up to 40 *VTEXT* characters.

Utility Custom 10 examples are the same as Utility Custom 1.

The Neptune® 360™ File Mapper export file contains records and field data that communicate premises and billing-related data from Neptune 360 back to the CIS. Many field values in an export file are sourced within Neptune 360, from a handheld device, or from a register or sensor device. Some field values in the export file are passed through from Import Record data sourced by the CIS.

The export file consists of two components: the Export Header Row and the Export Records.

## Export Header Row

The Export Header Row contains the column names and represents all the Neptune 360 File Mapper export fields included in the Export Record. There can only be **one** Export Header Row in an export file, and it is the first row / record in the file.

The Export Header Row is 1,507 total characters including 1,505 *ALPHANUM* and *DELIM* characters followed by a terminating *CRLF*. The Export Header Row consists of the following literal text:

```
Company|Office|Cycle|Route|Account Number|Premises Key|Meter
Number_A|MIU ID_A|Register ID_A| Reading_A|Raw Reading_A|Read
DateTime_A|35 Day No Flow flag_A|Reverse Flow flag_A|35 Day leak
flag_A| Current Leak flag_A|Reader ID_A|Order Status_A|Skip
Code_A|Comment Code 1_A|Comment Code 2_A|Note_A| Re-entry Count_
A|Meter Number_B|MIU ID_B|Register ID_B|Reading_B|Raw Reading_
B|Read DateTime_B| 35 Day No Flow Flag_B|Reverse Flow Flag_B|35
Day leak Flag_B|Current Leak Flag_B|Reader ID_B| Order Status_
B|Skip Code_B|Comment Code 1_B|Comment Code 2_B|Note_B|Re-entry
Count_B|Meter Number_C| MIU ID_C|Register ID_C|Reading_C|Raw
Reading_C|Read DateTime_C|35 Day No Flow Flag_C| Reverse Flow
Flag_C|35 Day Leak Flag_C|Current Leak Flag_C|Reader ID_C|Order
Status_C|Skip Code_C| Comment Code 1_C|Comment Code 2_C|Note_
C|Re-entry count_C|Meter Number_D|MIU ID_D|Register ID_D|
Reading_D|Raw Reading_D|Read DateTime_D|35 Day No Flow Flag_
D|Reverse Flow Flag_D|35 Day leak Flag_D| Current Leak Flag_
D|Reader ID_D|Order Status_D|Skip Code_D|Comment Code 1_
D|Comment Code 2_D|Note_D| Re-entry Count_D|Meter Number_E|MIU
ID_E|Register ID_E|Reading_E|Raw Reading_E|Read DateTime_E| 35
Day No Flow Flag_E|Reverse Flow Flag_E|35 Day leak Flag_
E|Current Leak Flag_E|Reader ID_E| Order Status_E|Skip Code_
E|Comment Code 1_E|Comment Code 2_E|Note_E|Re-entry Count_
E|Utility Custom 1| Utility Custom 2|Utility Custom 3|Utility
Custom 4|Utility Custom 5|Utility Custom 6|Utility Custom 7|
Utility Custom 8|Utility Custom 9|Utility Custom 10
```



The line breaks in the above text presentation are for clarity in reading this document. There is no white space between a *DELIM* character and the subsequent text.

## Export Record

---

The Export Record transfers meter reading data from Neptune 360 back to the CIS. Each Export Record contains 101 fields / columns which correlate with the columns named in the Export Header Row record. The Export Record is logically organized into categories, although there is no visual or other separator within the record to demarcate these sections.

This section identifies and describes each of the fields in the Export Record and appears in the order presented in the Export Header Row. An export file may have any quantity of Export Records; however, there is at least one Export Record per file. The *DELIM* character separates each data field within the Export Record and each Export Record in the file ends with *CRLF*.

Some field values in the Export Record reflect values provided to Neptune 360 in an import file. Reading-related field values are sourced by Neptune 360, a handheld device, or a register or other metrology device. Each Export Record field includes:

- Field name
- Field description
- Example data

Requirements for the field's use (including any expected and or allowed values) are specified along with the character type and minimum and maximum allowed character counts.



An Export Record does NOT have any field data enclosed in *DQUOTE* characters unless the field data were enclosed in *DQUOTE* characters when imported from the CIS.

## ROUTE MANAGEMENT

---

The CIS sources all Route Management fields (Company, Office, Cycle, and Route), which pass through from the Import Record to the Export Record unchanged.

### Company

Company has the same value in the Export Record as was in the Import Record and contains up to four *ALPHANUM* characters.

Company examples:

- **NEPT** |
- **nep** |
- **00A1** |

### Office

Office has the same value in the Export Record as in the Import Record and contains up to four *ALPHANUM* characters.

Office examples:

- **Off1** |
- **1234** |
- **Of 1** |

### Cycle

Cycle has the same value in the Export Record as in the Import Record and contains up to four *ALPHANUM* characters.

Cycle examples:

- **Mwk1** |
- **0 02** |
- **A** |

### Route

Route has the same value in the Export Record as in the Import Record and contains up to 10 *ALPHANUM* characters.

Route examples:

- **DuluthGA01** |
- **DULUTH1** |
- **22** |

## ACCOUNT and PREMISES INFORMATION

---

These few Account and Premises Information fields are present in the Export Record to facilitate matching with the corresponding Import Record the CIS produces. The CIS sources all Account and Premises Information fields, which pass through from the Import Record to the Export Record unchanged.

### *Account Number*

Account Number has the same value in the Export Record as in the Import Record and contains at least 1 and up to 20 *ALPHANUM* characters.

Account Number examples:

- **DLTH0987654321 |**
- **abcde12345fghjk67890 |**
- **123-0000293847 |**

### *Premises Key*

Premises Key has the same value in the Export Record as in the Import Record and contains at least 1 and up to 20 *ALPHANUM* characters.

Premises Key examples:

- **001-1234567890 |**
- **A270C75BB6398AE02D14 |**
- **"102 /9876543" |**

## METER READING INFORMATION

---

The Meter Reading Information category of fields provides meter reading-related data from Neptune 360 back to the CIS for the purposes of billing. The Export Record includes five (5) independent Meter Reading structures which correlate with the meter configurations in the Import Record. Field descriptions, requirements for use, and examples are given for Meter Reading\_A. Those same specifications apply to each of Meter Reading\_B, Meter Reading\_C, Meter Reading\_D, and Meter Reading\_E.

An Export Record only includes Meter Reading data for the same meter configurations specified in the corresponding Import Record. For Meter configurations not specified in an Import Record, all corresponding Meter Reading fields are empty in the Export Record. For example, if only Meter\_A and Meter\_B were specified in an Import Record, only Meter Reading\_A and Meter Reading\_B contain data in the Export Record. The CIS sources some Meter Reading fields, which pass through from the Import Record to the Export Record unchanged.

## METER\_READING\_A

---

### *Meter Number\_A*

Meter Number\_A has the same value in the Export Record as in the Import Record and contains up to 20 *ALPHANUM* characters.

Meter Number\_A examples:

- **W1AH8201 |**
- **09876543211234567890 |**

### *MIU ID\_A*

MIU ID\_A has the same value in the Export Record as in the Import Record and contains up to 13 *DIGIT* characters.

MIU ID\_A examples:

- **1112223333 |**
- **2223334444555 |**

### *Register ID\_A*

Register ID\_A has the same value in the Export Record as in the Import Record and contains up to 10 *DIGIT* characters.

Register ID\_A examples:

- **1234867530 |**
- **2011417 |**

### *Reading\_A*

Represents the meter reading for the order formatted using Number of Dials. Reading should be specified; if present, it contains at least one and up to eight *DIGIT* characters for a normal, numeric register reading.

Reading\_A examples:

- **3108 |** (Number of Dials = 4)
- **002407 |** (Number of Dials = 6)
- **:::~::~: |** (read error)

Reading can represent either a reading manually keyed into a handheld device or a reading collected via radio or probe. If Order Status has a value of “skipped” or “incomplete,” the corresponding Reading is not specified. Reading may contain leading zeros and may contain up to eight *ERRREAD* characters.

### Raw Reading\_A

Represents all transmittable digits for a radio or probe-collected meter reading on the order. Raw Reading should be specified; if present, it contains at least six and up to eight *DIGIT* characters for a normal, numeric register reading.

Raw Reading\_A examples:

- **31082302|** (radio read)
- **074326|** (probe read)
- **:::~::~:|**(read error)

If Order Status has a value of “skipped” or “incomplete,” or if the reading for an order was manually keyed and the corresponding Raw Reading is not specified. Raw Reading may contain leading zeros and may contain up to eight *ERRREAD* characters.

### Read DateTime\_A

Represents the UTC date and time the Order Status was recorded. Read DateTime contains 20 *ALPHANUM* characters and is expressed in MM/DD/YYYY 24HH:MM:SS format.

Read DateTime\_A examples:

- **08/01/2019 18:37:21|**
- **12/14/2018 01:12:58|**

### 35 Day No Flow flag\_A

Code representing a range of consecutive days out of the previous 35 days the system recorded no consumption (no flow) for a register. A 35 Day No Flow flag may be specified; if present, it is one *DIGIT* character and one of the following values:

- **0** = 0 days (flow every day) **4** = 15 to 21 days
- **1** = 1 to 2 days **5** = 22 to 34 days
- **2** = 3 to 7 days **6** = 35 days (no flow detected)
- **3** = 8 to 14 days
- **4** = 15 to 21 days
- **5** = 22 to 34 days
- **6** = 35 days (no flow detected)

35 Day No Flow flag\_A examples:

- **0|**
- **6|**



Only a register operating in E-CODER PLUS mode reports a 35 Day No Flow flag. For all other register types (or if the reading for an E-CODER register has been manually keyed), 35 Day No Flow flag is empty. If there are multiple, separate periods of consecutive days with no consumption, the 35 Day No Flow flag returns the code that correlates with the longest period. If a value of **7** is received for 35 Day No Flow flag, you can ignore it.

### *Reverse Flow flag\_A*

Code indicating the level of any reverse flow event measured by a register within the past 24-hours. Reverse Flow flag may be specified; if present, it is one *DIGIT* character and one of the following values:

- **0** = No reverse flow indicated
- **1** = minor reverse flow
- **2** = major reverse flow

Reverse Flow flag\_A examples (all valid values):

- **0|**
- **1|**
- **2|**

Only a register operating in E-CODER PLUS mode reports Reverse Flow flag. For all other register types, or if the reading for an E-CODER register has been manually keyed, Reverse Flow flag is empty. The water volumes that trigger values of **1** or **2** for Reverse Flow flag vary based on meter size and register unit of measure. If a value of **3** is received for Reverse Flow flag, you can ignore it.

### *35 Day Leak flag\_A*

Code representing a range of the total number of days out of the previous 35 there was intermittent or continuous consumption reported by a register. The 35 Day Leak flag may be specified; if present, it is one *DIGIT* character and one of the following values:

- **0** = 0 days
- **1** = 1 to 2 days
- **2** = 3 to 7 days
- **3** = 8 to 14 days
- **4** = 15 to 21 days
- **5** = 22 to 34 days
- **6** = 35 days (intermittent or continuous consumption every day)

35 Day Leak flag \_A examples:

- **5|**
- **2|**

Only a register operating in E-CODER PLUS mode reports 5 Day Leak flag. For all other register types, or if the reading for an E-CODER register has been manually keyed, 35 Day Leak flag is empty. If a value of **7** is received for 35 Day Leak flag, you can ignore it.

### *Current Leak flag\_A*

Code categorizing the quantity of 15-minute periods of consumption measured by a register within the past 24-hours. Current Leak flag MAY be specified; if present, it is one *DIGIT* character and one of the following values:

- **0** = normal (0 to 49 15-minute periods within 24 hours)
- **1** = intermittent consumption (50 to 95 15-minute periods within 24 hours)
- **2** = continuous consumption (All 96 15-minute periods within 24 hours)

Current Leak flag \_A examples (all valid values):

- **0|**
- **1|**
- **2|**

Only a register operating in E-CODER PLUS mode reports Current Leak flag. For all other register types, or if the reading for an E-CODER register has been manually keyed, Current Leak flag is empty. A value of **1** or **2** for Current Leak flag may indicate a leak condition at the premises associated with the register. If a value of **3** is received for Current Leak flag, you can ignore it.

### *Reader ID\_A*

Identifies the person or handheld device that obtained the reading for the order. Reader ID is at least 1 and up to 50 *ALPHANUM* characters.

Reader ID\_A examples:

- **bmadison@neptune360.com|**
- **HANDHELD12|**

Reader ID should be a Neptune 360 username (email address) and may be a handheld device identifier depending on the device used. Note that the data in the Reader ID field may appear truncated.

### Order Status\_A

Indicates the status of the order when it was recorded. Order Status is up to 10 *ALPHA* characters and one of the following values:

- **Complete** = valid reading obtained
- **Incomplete** = reading not yet obtained
- **Skipped** = reading not obtained and skip code applied

Order Status\_A examples (all valid values):

- **Complete|**
- **Incomplete|**
- **Skipped|**

### Skip Code\_A

Code entered on a handheld device indicating a specific reason why a reading for an order was not obtained. Skip Code may be specified; if present it is at least one and up to four *ALPHANUM* characters.

Skip Code 1\_A examples:

- **SK01|**
- **s3|**

Skip Code is specified if Order Status has a value of "skipped" and is specified if Order Status is either "complete" or "incomplete." All Skip Code values and related descriptions originate within Neptune 360.

### Comment Code 1\_A

Code entered on a handheld device representing a meter situation or conditions at the premise which could affect obtaining a reading on future orders. Comment Code 1 may be specified and can contain up to four *ALPHANUM* characters.

Comment Code 1\_A examples:

- **INSC|**
- **c7|**

Comment Code 1 may be associated to an order via a handheld device. All Comment Code values and related descriptions originate within Neptune 360.

### Comment Code 2\_A

Code representing an additional meter situation or condition at the premise. Comment Code 2 may be specified and can contain up to four *ALPHANUM* characters.

Comment Code 2\_A examples same as Comment Code 1\_A.

Comment Code 2 may be associated to an order via a handheld device. All Comment Code values and related descriptions originate within Neptune 360.

#### *Note\_A*

Represents freeform text notes input on a handheld device regarding a premises or meters at a premises.

Note may be specified and can contain up to 128 *ALPHANUM* characters.

Note\_A examples:

- **mulch and dirt covering pit cover|**
- **major renovation@residence; owner says water shut off inside|**

#### *Re-entry Count\_A*

Indicates the number of different manually keyed readings attempted by a user for the order. Re-entry Count may be specified; if present, it is one *DIGIT* character.

Re-entry Count\_A examples:

- **1|**
- **6|**

#### METER READING\_B

---

##### *Meter Number\_B*

Meter Number\_B has the same value in the Export Record as in the Import Record and contains up to 20 *ALPHANUM* characters.

Meter Number\_B examples are the same as Meter Number\_A.

##### *MIU ID\_B*

MIU ID\_B has the same value in the Export Record as in the Import Record and contains up to 13 *DIGIT* characters.

MIU ID\_B examples are the same as MIU ID\_A.

##### *Register ID\_B*

Register ID\_A has the same value in the Export Record as in the Import Record and contains up to 10 *DIGIT* characters.

Register ID\_B examples are the same as Register ID\_A.

##### *Reading\_B*

Same meaning, requirements, and examples as Reading\_A.

*Raw Reading\_B*

Same meaning, requirements, and examples as Raw Reading\_A.

*Read DateTime\_B*

Same meaning, requirements, and examples as Read DateTime\_A.

*35 Day No Flow flag\_B*

Same meaning, requirements, and examples as 35 Day No Flow flag\_A.

*Reverse Flow flag\_B*

Same meaning, requirements, and examples as Reverse Flow flag\_A.

*35 Day Leak flag\_B*

Same meaning, requirements, and examples as 35 Day Leak flag\_A.

*Current Leak flag\_B*

Same meaning, requirements, and examples as Current Leak flag\_A.

*Reader ID\_B*

Same meaning, requirements, and examples as Reader ID\_A.

*Order Status\_B*

Same meaning, requirements, and examples as Order Status\_A.

*Skip Code\_B*

Same meaning, requirements, and examples as Skip Code\_A.

*Comment Code 1\_B*

Same meaning, requirements, and examples as Comment Code 1\_A,

*Comment Code 2\_B*

Same meaning, requirements, and examples as Comment Code 2\_A.

*Note\_B*

Same meaning, requirements, and examples as Note\_A.

*Re-entry Count\_B*

Same meaning, requirements, and examples as Re-entry Count\_A.

## METER READING\_C

### *Meter Number\_C*

Meter Number\_C has the same value in the Export Record as in the Import Record and contains up to 20 **ALPHANUM** characters.

Meter Number\_C examples are the same as Meter Number\_A.

### *MIU ID\_C*

MIU ID\_C has the same value in the Export Record as in the Import Record and contains up to 13 **DIGIT** characters.

MIU ID\_C examples are the same as MIU ID\_A.

### *Register ID\_C*

Register ID\_A has the same value in the Export Record as in the Import Record and contains up to 10 **DIGIT** characters.

Register ID\_C examples are the same as Register ID\_A.

### *Reading\_C*

Same meaning, requirements, and examples as Reading\_A.

### *Raw Reading\_C*

Same meaning, requirements, and examples as Raw Reading\_A.

### *Read DateTime\_C*

Same meaning, requirements, and examples as Read DateTime\_A.

### *35 Day No Flow flag\_C*

Same meaning, requirements, and examples as 35 Day No Flow flag\_A.

### *Reverse Flow flag\_C*

Same meaning, requirements, and examples as Reverse Flow flag\_A.

### *35 Day Leak flag\_C*

Same meaning, requirements, and examples as 35 Day Leak flag\_A.

### *Current Leak flag\_C*

Same meaning, requirements, and examples as Current Leak flag\_A.

### *Reader ID\_C*

Same meaning, requirements, and examples as Reader ID\_A.

### *Order Status\_C*

Same meaning, requirements, and examples as Order Status\_A.

### *Skip Code\_C*

Same meaning, requirements, and examples as Skip Code\_A.

### *Comment Code 1\_C*

Same meaning, requirements, and examples as Comment Code 1\_A,

### *Comment Code 2\_C*

Same meaning, requirements, and examples as Comment Code 2\_A.

### *Note\_C*

Same meaning, requirements, and examples as Note\_A.

### *Re-entry Count\_C*

Same meaning, requirements, and examples as Re-entry Count\_A.

## METER READING\_D

### *Meter Number\_D*

Meter Number\_D has the same value in the Export Record as in the Import Record and contains up to 20 **ALPHANUM** characters.

Meter Number\_D examples are the same as Meter Number\_A.

### *MIU ID\_D*

MIU ID\_D has the same value in the Export Record as in the Import Record and contains up to 13 **DIGIT** characters.

MIU ID\_D examples are the same as MIU ID\_A.

### *Register ID\_D*

Register ID\_A has the same value in the Export Record as in the Import Record and contains up to 10 **DIGIT** characters.

Register ID\_D examples are the same as Register ID\_A.

### *Reading\_D*

Same meaning, requirements, and examples as Reading\_A.

### *Raw Reading\_D*

Same meaning, requirements, and examples as Raw Reading\_A.

*Read DateTime\_D*

Same meaning, requirements, and examples as Read DateTime\_A.

*35 Day No Flow flag\_D*

Same meaning, requirements, and examples as 35 Day No Flow flag\_A.

*Reverse Flow flag\_D*

Same meaning, requirements, and examples as Reverse Flow flag\_A.

*35 Day Leak flag\_D*

Same meaning, requirements, and examples as 35 Day Leak flag\_A.

*Current Leak flag\_D*

Same meaning, requirements, and examples as Current Leak flag\_A.

*Reader ID\_D*

Same meaning, requirements, and examples as Reader ID\_A.

*Order Status\_D*

Same meaning, requirements, and examples as Order Status\_A.

*Skip Code\_D*

Same meaning, requirements, and examples as Skip Code\_A.

*Comment Code 1\_D*

Same meaning, requirements, and examples as Comment Code 1\_A.

*Comment Code 2\_D*

Same meaning, requirements, and examples as Comment Code 2\_A.

*Note\_D*

Same meaning, requirements, and examples as Note\_A.

*Re-entry Count\_D*

Same meaning, requirements, and examples as Re-entry Count\_A.



---

## METER READING\_E

---

### *Meter Number\_E*

Meter Number\_E has the same value in the Export Record as in the Import Record and contains up to 20 **ALPHANUM** characters.

Meter Number\_E examples are the same as Meter Number\_A.

### *MIU ID\_E*

MIU ID\_E has the same value in the Export Record as in the Import Record and contains up to 13 **DIGIT** characters.

MIU ID\_E examples are the same as MIU ID\_A.

### *Register ID\_E*

Register ID\_A has the same value in the Export Record as in the Import Record and contains up to 10 **DIGIT** characters.

Register ID\_E examples are the same as Register ID\_A.

### *Reading\_E*

Same meaning, requirements, and examples as Reading\_A.

### *Raw Reading\_E*

Same meaning, requirements, and examples as Raw Reading\_A.

### *Read DateTime\_E*

Same meaning, requirements, and examples as Read DateTime\_A.

### *35 Day No Flow flag\_E*

Same meaning, requirements, and examples as 35 Day No Flow flag\_A.

### *Reverse Flow flag\_E*

Same meaning, requirements, and examples as Reverse Flow flag\_A.

### *35 Day Leak flag\_E*

Same meaning, requirements, and examples as 35 Day Leak flag\_A.

### *Current Leak flag\_E*

Same meaning, requirements, and examples as Current Leak flag\_A.

### *Reader ID\_E*

Same meaning, requirements, and examples as Reader ID\_A.

### *Order Status\_E*

Same meaning, requirements, and examples as Order Status\_A.

### *Skip Code\_E*

Same meaning, requirements, and examples as Skip Code\_A.

### *Comment Code 1\_E*

Same meaning, requirements, and examples as Comment Code 1\_A.

### *Comment Code 2\_E*

Same meaning, requirements, and examples as Comment Code 2\_A.

### *Note\_E*

Same meaning, requirements, and examples as Note\_A.

### *Re-entry Count\_E*

Same meaning, requirements, and examples as Re-entry Count\_A.

## UTILITY PASS THROUGH

The CIS sources all Utility Pass Through fields, which pass through from the Import Record to the Export Record unchanged.

### *Utility Custom 1*

If specified in the Import Record, Utility Custom 1 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 1 examples:

- **Check w/bldg mgr. before accessing meter|**
- **001 /17590378164|**

### *Utility Custom 2*

If specified in the Import Record, Utility Custom 2 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 2 examples are the same as Utility Custom 1.

### *Utility Custom 3*

If specified in the Import Record, Utility Custom 3 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 3 examples are the same as Utility Custom 1.

#### Utility Custom 4

If specified in the Import Record, Utility Custom 4 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 2 examples are the same as Utility Custom 1.

#### Utility Custom 5

If specified in the Import Record, Utility Custom 5 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 5 examples are the same as Utility Custom 1.

#### Utility Custom 6

If specified in the Import Record, Utility Custom 6 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 6 examples are the same as Utility Custom 1.

#### Utility Custom 7

If specified in the Import Record, Utility Custom 7 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 7 examples are the same as Utility Custom 1.

#### Utility Custom 8

If specified in the Import Record, Utility Custom 8 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 8 examples are the same as Utility Custom 1.

#### Utility Custom 9

If specified in the Import Record, Utility Custom 9 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 9 examples are the same as Utility Custom 1.

#### Utility Custom 10

If specified in the Import Record, Utility Custom 10 has the same value in the Export Record and may contain up to 40 **ALPHANUM** characters.

Utility Custom 10 examples are the same as Utility Custom 1.

### Export Record Terminator

Each Export Record in an export file is terminated with a **CRLF**.

This page intentionally left blank.





**Neptune Technology Group Inc.**

1600 Alabama Highway 229  
Tallahassee, AL 36078  
USA Tel: (800) 633-8754  
Fax: (334) 283-7293

**Neptune Technology Group  
(Canada) Ltd.**

7275 West Credit Avenue  
Mississauga, Ontario L5N 5M9  
Canada Tel: (905) 858-4211  
Fax: (905) 858-0428

**Neptune Technology Group Inc.**

Avenida Ejercito Nacional No 418  
Piso 12, Despacho 1203  
Colonia Polanco V Sección  
C.P. 11560 Delegación, Miguel Hidalgo  
Mexico D.F.  
Tel: (55) 5203-5708, (55) 5203-4032,  
(55) 5203-5294

Online  
[www.neptunetg.com](http://www.neptunetg.com)

**Accu-Flo**  
1-800-921-2228  
[www.accuflo.com](http://www.accuflo.com)